

Intelligent Handheld Controller.

This remote control offers the function of monitoring the vehicle battery conditions and let the operator know by the indicators

When the left battery indicator flashes in **RED** and **Alarms**, this means the there's not enough power coming from the battery for winching. In this case the winching should stop immediately and make sure the vehicle is charging your battery ,the min battery required for winching is 650CCA.