

SOLENOID WIRING FOR THE SMALLER CONTROL BOX

Main Solenoid Terminals:

Terminal 1+ = Main (+ Pos) Battery Lead

Terminal 2 = Short Red to (Armature) Motor

Terminal 3 = Short Black (Yellow....In) Motor

Terminal 4 = Short Black (Black....Out) Motor

Solenoid Wiring:

Green/Yellow = Earth

Yellow/Green Stripe = + Positive

Brown = (In) connected to wireless remote receiver (Yellow)

Blue = (Out) connected to wireless remote receiver (White)

Wireless Remote Receiver Wiring:

Blue = Aerial

Black = Earth

Red = + Pos

White = Out

Yellow = In